

ALUCO™

Steel Look Collection



ALUCO INTERIOR DOOR HANDING GUIDE

All ALUCO interior doors are designed specifically for internal applications. When choosing an ALUCO interior door your new door does not have to open the same as your existing door.

ALUCO INTERIOR DOOR HANDING GUIDE


WHEN ORDERING YOUR ALUCO DOOR YOU NEED TO SPECIFY THE HANDING, LEFT HAND OR RIGHT HAND.

TO DO THIS STAND OUTSIDE OF THE ROOM YOU WANT THE NEW DOOR TO OPEN IN TO SO THAT THE DOOR OPENS AWAY FROM YOU.

AS AN EXAMPLE:

For a bedroom door that will open into the bedroom, stand in the hallway facing the bedroom door. The door should always open away from you.

Handing is recognised by the side the hinges are on. If the door opens as the image on the right you will require a **RIGHT HAND DOOR**.



DETERMINING YOUR NEW DOOR HANDING

Face the door so that the new door opens away from you, into the room you are facing.

Based on the images on the right determine the correct handing is based on the side of the door the hinges are.

